

Step 1: With the pin positioned on the gate and in front of the latch post, position the latch to make contact with the pin on the rest plate as shown. With a marker make two dots at the slot centers to position the holes for the bolts.

Step 2: Drill clearance holes for two 3/8" through bolts or a 5/16" hole if using lag screws when screwing directly to the post. Stainless steel lag screws and washers are provided. Due to the various sizes of posts the through bolts are not included in the kit and are an optional mounting method.

BuckleyFence.com 877.306.4024